


# F control kit

Model: **991-006** 

Sun offers a selection of both general purpose and special purpose adjustment controls. General purpose controls are for use in systems where adjustments may be changed after installation. Sun's L control option is a general purpose control which is specified at time of order. An L control field replacement kit is available for certain older model counterbalance cartridges. Special purpose controls are for use in systems where adjustment is seldom changed after installation and include the F and J control options.













### **Technical Features**

- F and J Control Kits: To assure a complete seal on the stem release all pressure on the cartridge after setting. Then tighten locknut (and cap, on J).
- F and J Control Kits: For use in systems where adjustment is seldom changed after installation.
- F Control Kit: A stem seal o-ring is provided for under the locknut. The adjustment screw is not retained. Overset protection is provided; the spring can not go solid.
- The installation of this kit is intended to be permanent. Once assembled to the cartridge, it cannot be easily readjusted or disassembled.

## Technical Data

U.S. Units	Metric Units
F Control	
PBFB, RBAA, RBAC, RBAT, RHEA, RPEC, RPEE, RPGB, RPGE, RPGC, RQEB, RSFC, SQFB	
All Models with F Control	
Zinc Plated Steel	
Adjustment Screw Kit	
0.05 lb.	0.02 kg.
	F Co PBFB, RBAA, RBAC, RBAT, RPGE, RPGC, RO All Models v Zinc Pla Adjustmer

# 991-006

Display Components		
	Description	Quantity
350-003	Locknut	1
325-020	Adjustment Screw	1
550-015	O-Ring	1
999-991-006	Literature	1

#### Instructions/Notes

• To assure a complete seal on the stem, release all pressure on the cartridge after setting. Then tighten locknut (and cap, on J).